RECOMMENDED GUIDELINES FOR FITTING CURVES

One piece curves

1. Before fitting, place curve on step to ensure that it fits properly.
2. All curves are produced with 50mm oversize on each end of the curve, to allow for trimming on site (see diagram A).
3. To establish exactly where the curve needs to be trimmed, we recommend taking a template of the step with a good quality felt paper.
4. Next overlay this template onto the curve, mark and trim accordingly.
5. Offer curve to step, if the section fits correctly then fix with recommended fixing method.

DIAGRAM A

Curves made up of more than one piece

PLEASE NOTE: The centre sections of curves consisting of more than 1 piece will have ready cut joints that will simply butt together. The end sections will be produced with 50mm oversize to allow for trimming on site.

Joints will be marked A > A, B > B, etc. (see diagram B).

1. Fit end section first, please note that this piece will have 50mm oversize to cut in.
2. Fit centre curve(s) next, this does not require cutting in, and fit flush to joint, fit A > A, B > B etc until you come to the final piece.
3. Finally fit the other end curve and cut in as normal.
4. Fix curves with recommended adhesive and secure with screws.

DIAGRAM B



Quantum Profile Systems Ltd
Salmon Fields, Royton, Oldham, OL2 6JG, UK
tel: +44 (0) 161 627 4222
info@quantumflooring.co.uk
fax: +44 (0) 161 627 4333
www.quantumflooring.co.uk