FITTING GUIDE
PUSH-ON GLAZING BEADS

Required Profiles:

QW-GB5 (SD1) Push-on glazing bead
Push-on clip / 'clip-packers'
Glazing tape



Once the glazing unit is safely in position, push in base 'clip-packers'; 40 mm from each corner and then every 150 mm along base. Remove standard packers if desired.



Place and pin 'clip-packers' 40 mm from each corner and then every 150 mm around the glazed unit up the jambs and across the top. Use appropriate coloured/thickness 'clip-packers' to provide a good friction fit.



Pin the base 'clip-packers' to frame to secure.



Apply strip of self-adhesive dry glaze tape to back edge of QW-GB5 (SD1) bead.



Starting with the base bead, peel off the protective paper strip from the dry glaze tape and push-fit the QW-GB5 (SD1) bead onto the 'clip-packers' along the base.



Repeat the process for the jambs and top. Make sure beads sit in line with frame and does not protrude.



Using a felt covered block, from the front, gently tap the QW-GB5 (SD1) beads around the glazing unit to ensure that they are firmly in place and a good bond between the dry glaze tape and glass has been achieved.

Available from:

SDH
SASH + DOOR
HARDWARE

If you require any further information or assistance with the fitting of any Qwood product, please contact us:

+44 (0) 161 627 4222

info@qwood.co.uk

www.qwood.co.uk

FITTING GUIDE
PUSH-ON GLAZING BEADS

Clip position and spacing recommendation:



Recommendations for dark colours:

» Clip spacing at 150mm centered

» Apply pin to the outmost edges of each bead to aid stability

» Where possible pin beads down in concealed places

If you require any further information or assistance with the fitting of any Qwood product, please contact us:

+44 (0) 161 627 4222 info@qwood.co.uk www.qwood.co.uk

Quantum Profile Systems Ltd, Salmon Fields, Royton, Oldham, OL2 6JG, UK